

Villa Door Station

User Manual



V1.0.3

Foreword

General

This manual introduces the installation, functions and operations of the villa door station device (hereinafter referred to as "the VTO"). Read carefully before using the device, and keep the manual safe for future reference.

Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, reductions in performance, or unpredictable results.
 NOTE	Provides additional information as a supplement to the text.

Revision History

Version	Revision Content	Release Date
V1.0.3	Updated the front panel.	November 2025
V1.0.2	Updated RS-485.	August 2025
V1.0.1	<ul style="list-style-type: none">Updated the basic settings.Updated the cloud service.	June 2025
V1.0.0	First release.	November 2024

Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, audio, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.

- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.
- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper user manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguard and Warnings

This section introduces content covering the proper handling of the device, hazard prevention, and prevention of property damage. Read carefully before using the device, and comply with the guidelines when using it.

Installation Requirements



- Do not connect the power adapter to the device while the adapter is powered on.
- Do not connect the device to two or more kinds of power supplies, to avoid damage to the device.
- Please follow the electrical requirements to power the device.
 - ◇ Following are the requirements for selecting a power adapter.
 - The power supply must conform to the requirements of IEC 60950-1 and IEC 62368-1 standards.
 - The voltage must meet the SELV (Safety Extra Low Voltage) requirements and not exceed ES-1 standards.
 - When the power of the device does not exceed 100 W, the power supply must meet LPS requirements and be no higher than PS2.
 - ◇ We recommend using the power adapter provided with the device.
 - ◇ When selecting the power adapter, the power supply requirements (such as rated voltage) are subject to the device label.



- Personnel working at heights must take all necessary measures to ensure personal safety including wearing a helmet and safety belts.
- Do not place the device in a place exposed to sunlight or near heat sources.
- Keep the device away from dampness, dust, and soot.
- Install the device on a stable surface to prevent it from falling.
- Install the device in a well-ventilated place, and do not block its ventilation.
- Use an adapter or cabinet power supply provided by the manufacturer.
- Use the power cords that are recommended for the region and conform to the rated power specifications.
- The device is a class I electrical appliance. Make sure that the power supply of the device is connected to a power socket with protective earthing.
- The device must be installed at a height of 2 meters or below.

Operation Requirements



Battery Pack Precautions

Preventive measures (including but not limited to):

- Do not transport, store or use the batteries in high altitudes with low pressure and environments with extremely high and low temperatures.

- Do not dispose the batteries in fire or a hot oven, or mechanically crush or cut the batteries to avoid an explosion.
- Do not leave the batteries in environments with extremely high temperatures to avoid explosions and leakage of flammable liquid or gas.
- Do not subject the batteries to extremely low air pressure to avoid explosions and the leakage of flammable liquid or gas.



- Check whether the power supply is correct before use.
- Do not unplug the power cord on the side of the device while the adapter is powered on.
- Operate the device within the rated range of power input and output.
- Transport, use and store the device under allowed humidity and temperature conditions.
- If the device is powered off for longer than a month, it should be placed in its original package and sealed. Make sure to keep it away from moisture, and store it under allowed humidity and temperature conditions.
- Do not drop or splash liquid onto the device, and make sure that there is no object filled with liquid on the device to prevent liquid from flowing into it.
- Do not disassemble the device without professional instruction.

Table of Contents

Foreword.....	I
Important Safeguard and Warnings.....	III
1 Structure.....	1
1.1 Villa Door Station (Multiple Buttons).....	1
1.1.1 Front Panel.....	1
1.1.2 Rear Panel.....	2
1.2 Villa Door Station (Single Button).....	3
1.2.1 R Series.....	3
1.2.2 D Series.....	5
1.2.3 G Series.....	8
1.2.4 E Series.....	9
1.2.5 F Series.....	15
1.3 Button Model.....	18
1.3.1 Front Panel.....	18
1.3.2 Rear Panel.....	19
2 Initializing the VTO.....	21
2.1 Webpage.....	21
2.2 DMSS App.....	21
2.3 DoLynk Care.....	25
3 Logging In and Resetting Password.....	26
3.1 Login.....	26
3.2 Resetting Password.....	26
4 Home Page.....	28
5 Setup Wizard.....	29
5.1 Setting as the SIP Server.....	29
5.2 Not Setting as the SIP Server.....	30
6 Local Device Configuration.....	31
6.1 Basic Settings.....	31
6.1.1 Villa Door Station.....	31
6.1.2 Second Confirmation Station.....	34
6.2 Access Control.....	36
6.2.1 Configuration.....	36
6.2.2 RS-485.....	38
6.3 Card Settings.....	39
6.4 Wiegand Settings.....	40
6.5 Layout (Multiple Buttons).....	42
7 Device Setting.....	45

7.1 VTO Management.....	45
7.2 VTH Management.....	46
7.3 VTS Management.....	49
8 Person Management.....	50
9 Network Settings.....	53
9.1 TCP/IP.....	53
9.2 Port.....	54
9.3 SIP Server.....	55
9.4 Second Confirmation Station Cascading.....	58
9.5 Cloud Service.....	59
9.6 Wi-Fi.....	60
9.7 Basic Services.....	61
9.8 Auto Registration.....	63
10 System.....	64
10.1 Alarm.....	64
10.2 Video.....	65
10.3 Audio.....	67
10.4 Time.....	69
10.5 ONVIF User.....	71
11 Maintenance Center.....	72
11.1 One-Click Diagnosis.....	72
11.2 System Information.....	72
11.2.1 Version Information.....	72
11.2.2 Legal Information.....	73
11.3 Data Capacity.....	73
11.4 Log Management.....	73
11.4.1 Call History.....	73
11.4.2 Alarm Logs.....	74
11.4.3 Unlock Records.....	74
11.4.4 Log.....	75
11.5 Maintenance Management.....	75
11.5.1 Config.....	75
11.5.2 Maintenance.....	76
11.6 Update.....	76
11.7 Advanced Maintenance.....	77
12 Security Management.....	79
12.1 Security Status.....	79
12.2 System Service.....	79
12.3 Attack Defense.....	80
12.3.1 Firewall.....	80

12.3.2 Account Lockout.....	81
12.3.3 Anti-DoS Attack.....	82
12.4 CA Certificate.....	82
12.5 Video Encryption.....	83
12.6 Security Warning.....	83
12.7 Security Authentication.....	84
13 Button Model Configuration.....	85
13.1 Cable Connection.....	85
13.2 VTH Configuration.....	86
Appendix 1 Security Recommendation.....	88

1 Structure

1.1 Villa Door Station (Multiple Buttons)

1.1.1 Front Panel

Figure 1-1 Front panel




Table 1-1 Components

No.	Name	Function
1	MIC	Audio input.
2	Illuminator	Provides a constant light to focus more easily on a subject in dark surroundings.
3	Camera	Captures images or record videos for the VTO.
4	Call buttons	Calls the VTH.
5	Card swiping area	Swipes the registered cards to unlock doors.
6	Indicators	From left to right: <ul style="list-style-type: none">● Ring: VTO is calling the VTH.● Talking: VTO is on the talk with the VTH.● Unlocking: VTO is unlocking successful.

1.1.2 Rear Panel



The multi-function port might differ depending on the actual models.

Figure 1-2 Rear panel




Table 1-2 Components

No.	Name	Function
1	SD card slot	Used to insert SD card so that data information such as images and videos can be stored.
2	Multi-function port	Alarm port, door detector port, 485 port, power port and other ports.
3	Network port	RJ-485 network port to connect to the network.
4	Reset button	Press and hold the button for several seconds to reset to factory settings.

1.2 Villa Door Station (Single Button)

1.2.1 R Series

1.2.1.1 Front Panel

Size and appearance might differ depending on the models of product.

Figure 1-3 Front panel




Table 1-3 Components

No.	Name	Function
1	MIC	Audio input.
2	Camera	Capture images or record videos for the VTO.
3	Call button	Call the VTH.
4	Card swiping area	Swipe the registered cards to unlock doors. The card swiping function is only available on select models.
5	Speaker	Audio output.

1.2.1.2 Rear Panel



The multi-function port might differ depending on the model. Here are two models used as examples.

Figure 1-4 Rear panel (1)




Table 1-4 Components

No.	Name	Function
1	Network port	Connects to the network.
2	SD card slot	Insert SD card so that data information such as images and videos can be stored.
3	Reset button	Press and hold the button for several seconds to reset to factory settings.
4	Multi-function port	<ul style="list-style-type: none"> Type 1: The multi-function port only has a power input port to connect to power supply. Type2: The multi-function port includes a power input port and a door detector port.

Figure 1-5 Rear panel (2)




Table 1-5 Components

No.	Name	Function
1	SD card slot	Insert SD card so that data information such as images and videos can be stored.
2	Power port	Connects to the power supply.
3	Reset button	Press and hold the button for several seconds to reset to factory settings.

1.2.2 D Series

1.2.2.1 Front Panel

Figure 1-6 Front panel




Table 1-6 Components

No.	Name	Function
1	MIC	Audio input.
2	Camera	Capture images or record videos for the VTO.
3	Call button	Call the VTH.
4	Speaker	Audio output.

1.2.2.2 Rear Panel

Figure 1-7 Rear panel




Table 1-7 Components

No.	Name	Function
1	Tamper button	<ul style="list-style-type: none"> After the installed device is removed from the wall or other places, the device beeps and the alarm record will be generated. Within 5 minutes after the device is powered on, if you press the tamper button for 5 times in 8 seconds, the device beeps and deletes the account information. The alarm record will be generated.
2	Multi-function ports	Alarm port, door detector port, 485 port, power port and more.
3	Network port	Connects to the network.
4	Reset button	Press and hold the button for several seconds to reset to factory settings.

1.2.3 G Series

1.2.3.1 Front Panel

Figure 1-8 Front panel




Table 1-8 Components

No.	Name	Function
1	MIC	Audio input.
2	Camera	Capture images or record videos for the VTO.
3	Call button	<p>Call the VTH.</p> <p>The button displays different colors in different statuses.</p> <ul style="list-style-type: none">● Standby: No light.● Call not answered: Solid green.● Call answered: Solid blue.● Unlock when the device is in standby status: Red.● Unlock when the call is not answered: Flashes green, yellow and then green.● Unlock after the call is answered: Flashes blue, pink and then blue.● Network disconnected: Green breathing light.
4	Speaker	Audio output.

1.2.3.2 Rear Panel

Figure 1-9 Rear panel





Table 1-9 Components

No.	Name	Function
1	Network port	Connects to the network.
2	Multi-function port	Alarm port, door detector port, 485 port, power port and more.
3	SD card slot	Insert SD card so that data information such as images and videos can be stored.
4	Tamper button	<ul style="list-style-type: none"> After the installed device is removed from the wall or other places, the device beeps and the alarm record will be generated. Within 5 minutes after the device is powered on, if you press the tamper button for 5 times in 8 seconds, the device beeps and deletes the account information. The alarm record will be generated.

1.2.4 E Series

1.2.4.1 Front Panel (3222E and 6222E)

Figure 1-10 Front panel




The panel on the left is the model of 3222E, and the one on the right is the model of 6222E.

Table 1-10 Front panel description

No.	Name	Description
1	Illuminator	Provides extra light for the camera when it is dark.
2	Microphone	Audio input.
3	Camera	Capture images or record videos for the VTO.
4	Indicators	Displays status on calling, talking and unlock.
5	Keypad	—
6	Card reading area	Swipe a card here to unlock the door.
7	Speaker	Audio output.

1.2.4.2 Rear Panel (3222E and 6222E)

Figure 1-11 Rear panel




The rear panels of the model of 3222E and 6222E are the same.

Table 1-11 Rear panel description

No.	Name	Description
1	Anti-tampering switch	When the VTO is removed from the wall forcibly, an alarm will be triggered and the alarm information will be sent to management center.
2	Multi-function port	For details, see Figure 1-12 .
3	SD card slot	Plug in the SD card.
4	Reset button	Press and hold it for 10 seconds to reset all settings.

Figure 1-12 Multi-function port



1.2.4.3 Front Panel (2101E)

Figure 1-13 Front panel




Table 1-12 Front panel description

No.	Name	Description
1	Microphone	—
2	Camera	—
3	IR illumination light	Provides extra IR light for the camera when it is dark.
4	Light sensor	Detects ambient lighting condition.
5	Call button	Call VTHs or the management center.
6	Speaker	—

1.2.4.4 Rear Panel (2101E)

Figure 1-14 Rear panel




Table 1-13 Rear panel description

No.	Name	Description
1	Network port	Connects to the network cable.
2	RS-485 ports	See the figure and the table below.
3	Cable outlet	Thread the cables here.

Figure 1-15 Cable connection




Table 1-14 Port description

DOOR		POWER/485	
No.	Name	No.	Name
1	NO	1	+12
2	NC	2	GND
3	COM	3	RS-485A
4	ALARM IN or Unlock (default)	4	RS-485B

1.2.5 F Series

1.2.5.1 Front Panel

Figure 1-16 Front panel




Table 1-15 Front panel description

No.	Name	Description
1	Microphone	Audio input.
2	Camera	Capture images or record videos for the VTO.
3	Indicators	Display status on calling, talking and unlock.
4	Speaker	Audio output.
5	Call button	Call button.
6	Nameplate	Displays the custom information.
7	Card slot and reset button	<ul style="list-style-type: none">● Insert SD card so that data information such as images and videos can be stored.● Press and hold the button for several seconds to reset to factory settings.

1.2.5.2 Rear Panel

Figure 1-17 Rear panel




Table 1-16 Rear panel description

No.	Name	Function
1	Tamper button	<ul style="list-style-type: none">After the installed device is removed from the wall or other places, the device beeps and the alarm record will be generated.Within 5 minutes after the device is powered on, if you press the tamper button for 5 times in 8 seconds, the device beeps and deletes the account information. The alarm record will be generated.
2	Multi-function ports	Alarm port, door detector port, 485 port, power port and more.
3	Network port	Connects to the network.

Figure 1-18 Multi-function ports




Table 1-17 Port description

No.	Description	No.	Description
1	GND	8	<ul style="list-style-type: none"> • 2 wires-(GND) for a digital 2-wire camera module • GND for a full digital camera module
2	+12V_OUT	9	DOOR_BUTTON
3	RS-485_B	10	DOOR_FEEDBACK
4	RS-485_A	11	GND
5	ALARM_NO	12	DOOR_NC
6	ALARM_COM	13	DOOR_COM
7	<ul style="list-style-type: none"> • 2wires+(48V) for a digital 2-wire camera module • 12 V_IN for a full digital camera module 	14	DOOR_NO

1.3 Button Model

1.3.1 Front Panel

Figure 1-19 Front panel




Table 1-18 Components

No.	Name	Function
1	Press button	The button model can be connected to the VTH. Press the button on the model and the VTH receives an alarm signal.

1.3.2 Rear Panel

Figure 1-20 Rear panel





Table 1-19 Components

No.	Name	Function
1	Multi-function port	Used for alarm input.

Figure 1-21 Cable connection



Connect the KEY port of the button model to any one of the alarm input ports of the indoor monitor (VTH) with a cable thread. After that, tap **Setting > Alarm > Wired Zone** on the VTH and set the **Type** of the alarm input port you chose to connect to the KEY port as **Doorbell**.

2 Initializing the VTO

2.1 Webpage

For first-time login, you need to initialize the VTO.

Procedure

Step 1 Power on the VTO.

Step 2 Go to the default IP address (192.168.1.108) of the VTO.



Make sure that the IP address of your PC is on the same network segment as the VTO.

Step 3 On the **Device Init** page, enter and confirm the password, and then click **Next**.



The password must consist of 8–32 non-blank characters and contain at least two types of the following characters: Uppercase, lowercase, numbers, and special characters (excluding ' " ; : &).

Step 4 Select the **Email** checkbox and enter an email address for resetting password.

Step 5 Click **Next**.

Step 6 Click **OK** to go to the login page.

Step 7 Enter the username (admin by default) and password to log in to the webpage.

2.2 DMSS App

If your model supports Wi-Fi connection to the network, you can initialize the VTO on the DMSS app. For detailed operation of the app, refer to its user manual.

Prerequisites

You have downloaded the DMSS in the App Store (iOS) or Google Play (Android), and have created an account and logged in to the app.

Procedure

Step 1 Power on the VTO.

Step 2 Enable hotspot on the VTO through pressing and holding the call button on the VTO until you heard the voice prompt.




The hotspot function is to enable you connect the VTO to the network through **AP configuration** on the app.

Step 3 Add the VTO to the DMSS app.

1. On the **Home** screen, tap , and then select **SN/Scan**.
2. Add a VTO.
3. You can add through scanning the QR code at the rear panel of the VTO.
4. The SN number of the VTO appears automatically, and then tap **Next**.
5. Select device type as **VTO**, and then the device information appears.
6. Tap **View Reasons**.

Figure 2-1 Add VTO to DMSS




7. Configure network by switch networking to **AP Configuration** , and then tap **Next**.
8. Connect your phone to the hotspot you just enabled on the VTO.



- The hotspot name is the SN number of your VTO.
- The current page will move on to the next step automatically after connection.

Figure 2-2 AP configuration



Step 4 Complete initialization based on instructions on the app.

1. Enter the password you planned for the VTO, and confirm it, and then tap **Next**.
2. Select **Cloud Access** and **Auto-check**, and then tap **OK**.

The initialization process is completed.

Figure 2-3 Initialization

Add Device

To guarantee device safety, please set device password.Usually, it will take 1 – 60s, please wait.

Username
admin

Please enter device password.

Weak

Medium

Strong

Please confirm the device password

Email (Optional)

The email address is used to receive the default password if you forget the device password.

Next

Cloud Update Configuration

Cloud Access

Register device to Cloud to prepare for you with cloud account to achieve cloud services such as remote monitoring, device recording,talking, alarm, cloud storage, and device management.If P2P is not enabled, you may not properly use functions such as intercom.

Auto-check

The system checks for update once a day automatically. There will be system notification if any update is available. Online update is a service that provides you with firmware updates by cloud. Your device information such as device name, firmware version and device SN will be collected in order to inform you about available firmware updates. All information is only used to inform you firmware updates.

OK

- Step 5** Connect the VTO to the network through Wi-Fi.
1. Select an available Wi-Fi.
 2. Enter the password and tap **Next**. Wait for the VTO to connect to the router.

Figure 2-4 Wi-Fi connection

Add Device

WLAN

home-1

home-2

home-3

home-4

Searching available Wi-Fi nearby ...

Add Device

Please connect to a Wi-Fi hotspot near you or to one that has a strong signal.

Add Device

Wi-Fi Network

Wi-Fi Password

Dual band router fails to support 5G Wi-Fi

Next

Add Device


58

Connecting to the router...

Cancel Config

- Step 6** Configure device name, and then tap **Save**.

Figure 2-6 Monitor




2.3 DoLynk Care

You can initialize the device on the DoLynk Care. Here uses initialization on DoLynk Care app as an example. For detailed operation of the app, refer to its user manual.

Procedure

- Step 1 On the home screen, tap .
- Step 2 Tap **QR**.
- Step 3 Scan device QR code, or tap  to manually enter device SN.
- Step 4 Select a site, and then tap **OK**.
- Step 5 On the **Add Device** screen, select a device type.
- Step 6 Connect to wireless or wired network.
- Step 7 Enter password and confirm it again, and then tap **Initialize the device** to complete initialization.

Figure 2-7 Initialize the device



- Step 8 Tap **Completed**, and then you can view the device in the device list.

3 Logging In and Resetting Password

3.1 Login

Before login, make sure that the computer is on the same network segment as the VTO.

Procedure


Step 1 Go to the IP address of the VTO in the browser.



For first-time login, enter the default IP (192.168.1.108). If you have multiple VTOs, we recommend that you change the default IP address to avoid conflict.

Step 2 Enter **admin** as the username, and enter the password you set during initialization, and then click **Login**.

Figure 3-1 Login



3.2 Resetting Password

Procedure

Step 1 On the login page, click **Forgot Password?**, and then click **Next**.

Step 2 Scan the QR code, and then you will get a string of numbers and letters.

Step 3 Send the string to the email account displayed on the page, and then the security code will be sent to the email address configured during initialization.

Step 4 Enter the security code in the input box, and then click **Next**.



- If you did not set an email address during initialization, contact your supplier or customer service for help.

- The security code will be valid only for 24 hours upon receipt.
- If you enter the wrong security code for 5 consecutive times, your account will be locked for 5 minutes.

Step 5 Enter and confirm the new password, and then click **OK**.

4 Home Page

Figure 4-1 Home page




Table 4-1 Home page introduction

No.	Function	Description
1	Home button	Go back to the home page.
2	Setup Wizard	Configure the VTO SIP server.
3	Navigation bar	<ul style="list-style-type: none"> : Change language of the webpage of the VTO. : Change password, log out of the current device, restart the system, and restore the device to factory settings. : View and configure the security settings. : Scan the QR code to get the product material. : View the webpage in full screen mode.
4	VTO function	Different function areas of the VTO.

5 Setup Wizard

- Through the setup wizard, you can finish the process of adding VTO/VTH and specific any VTO as the SIP server. You can also cancel its status of working as a SIP server.
- If the device has been added to the DoLynk Pro, the setup wizard will not shown.

5.1 Setting as the SIP Server

Set the VTO as the SIP server.

Prerequisites

You have added VTOs on the webpage. If not, you can add them in **Set as SIP Server** page or in the **Device Setting** section.

Procedure

- Step 1 Log in to the webpage of the VTO.
- Step 2 Select **Setup Wizard** > **Set as SIP Server**, and then click **Next**.

Figure 5-1 Set as SIP server

1 Step 1

2 Step 2

Set as SIP Server

Do not Set as SIP Server

Exit Next

- Step 3 Select the VTO to be set as the SIP server, and then click **OK**.
- You can also click **Add** to add VTOs if you have not had one to work as the SIP server.

Figure 5-2 Select the SIP server

1 Step 1

2 Step 2

Add Delete Clear Refresh

Please enter

Device Type	SIP No.	IP Address	Online Status	Operation
☐ VTO	8001	127.0.0.1	Online	
☐ VTH	9901#0		Offline	
☐ VTH	9901#1		Offline	
☐ VTH	9901#2		Offline	
☐ VTH	9901#3		Offline	
☐ VTH	9901#4		Offline	
☐ VTH	9901#5		Offline	
☐ VTH	9901#6		Offline	
☐ VTH	9901#7		Offline	
☐ VTH	9901#8		Offline	

11 records

10 / page Go to Page

Exit Back OK


5.2 Not Setting as the SIP Server

If you want to change the SIP server, you need to remove the current one from the list.

Procedure

- Step 1 Log in to the webpage of the VTO.
- Step 2 Select **Setup Wizard** > **Do not Set as SIP Server**, and then click **Next**.

Figure 5-3 Do not set as SIP server



- Step 3 Configure the information of the VTO that you do not want to set as SIP server, and then click **OK**.

Figure 5-4 Configure information

The screenshot shows a configuration window with a progress bar at the top indicating 'Step 1' is active and 'Step 2' is next. The main area contains several configuration fields for a VTO. The fields are: 'VTO ID' (text box with '8002'), 'Building No.' (text box with '0' and a checkbox), 'Unit No.' (text box with '0' and a checkbox), 'Server Type' (dropdown menu with 'Device' selected), 'Server Address' (text box with a masked address), 'Port' (text box with '5060'), 'SIP No.' (text box with '8001'), 'Registration Password' (password field with dots), 'SIP Domain' (text box with 'VDP'), 'SIP Server Username' (text box with 'admin'), and 'SIP Server Password' (password field with dots). At the bottom of the window, there are three buttons: 'Exit', 'Back', and 'OK'.

6 Local Device Configuration

This chapter introduces the detailed configuration of the VTO.



Slight differences might be found in different models.

6.1 Basic Settings

Configure basic settings of the device.

Background Information

If the device has been added to the DoLynk Pro, the device type can not be modified.

6.1.1 Villa Door Station

Procedure

- Step 1 Select **Local Device Config** > **Basic Settings**.
- Step 2 Configure the parameters.

Figure 6-1 Basic settings

Local Device Config

Device Type

Villa Station

Device Name

Villa Room No.

9901

Building No.

70

☒

Unit No.

0

☐

VTO ID

8001

Management Center

888888

Available Call Time

Setting

DND for DMSS

Setting

Calling by Period Mode

Enable

☐

Functions

Storage Method

SD Card

SD Card Usage

0M/0M

Format SD Card

If the SD card cannot be recognized, you can format it.

Auto Capture while Unlocking

☒

Auto Capture during Call

☒

Upload Messages and Videos

☒

Auto Record while Calling

☒

Please regularly perform backups to avoid data loss.

Apply

Refresh

Default

Table 6-1 Basic parameter description

Parameter	Description
Device Type	Select Villa Station .
Device Name	When other devices are monitoring this VTO, the device name will appear on the monitoring image.
Villa Room No.	VTH room number. Used to call VTHs.
Building No.	Configuring the building and unit number where the device is.
Unit No.	 <p>If you clear the Building No. and Unit No. checkbox, it means that there is just only 1 building and unit.</p>
VTO ID	<p>Used to differentiate each VTO, and we recommend you set it according to unit or building number, and then you can add VTOs to the SIP server by using their numbers.</p>  <p>The number cannot be changed when the VTO serves as the SIP server.</p>
Group Call	Enable it on the VTO that works as the SIP server, and when a main VTH receives a call, all extension VTHs will also receive the call.
Management Center	888888 by default.
Available Call Time	The time period in which the VTO's calling to other devices is limited. Click Setting to set the time plan for calling.
DND for DMSS	The time period in which the calling to DMSS is not limited. Click Setting to set the time plan for calling.
Calling by Period Mode	<ul style="list-style-type: none"> • If you enable the Calling by Period Mode, the specified number can be called in the specified period and the default number in other period. • Click Setting to set the time plan for calling.  <p>This function is only available when the mode is villa door station and second confirmation station.</p>
Storage Method	SD card by default.
SD Card Usage	Displays the total and used capacity of the SD card. You can click Format SD Card to delete all the data in the SD card.
Auto Capture while Unlocking	<p>Take a snapshot and save it in the SD card of the VTO when the VTO is unlocking.</p>  <p>If the VTO is unlock through local unlock button, the snapshot will not be taken.</p>

Parameter	Description
Auto Capture during Call	Take a snapshot and save it in the SD card of the VTO when the VTO is calling.
Upload Messages and Videos	<p>When enabled:</p> <ul style="list-style-type: none"> ● If an SD card is inserted in both the VTH and VTO, the video message will be saved both in the SD cards of the VTH and the VTO. ● If an SD card is only inserted in the VTH or the VTO, the video message will be saved only in the SD card of the VTH or the VTO. ● If no SD card is inserted in the VTH or VTO, no video message will be saved.
Auto Record while Calling	<p>Take recording when the VTO is in a call, and save the recording in the SD card of the VTO.</p>  <ul style="list-style-type: none"> ● When the call time is less than 5 seconds, no video file will be generated. ● If there is a conflict between Auto Record while Calling and Leave Videos, Leave Videos prevails.

Step 3 Click **Apply**.

6.1.2 Second Confirmation Station



The configuration of second confirmation station is available on select models.

Procedure

Step 1 Select **Local Device Config** > **Basic Settings**.

Step 2 Configure the parameters.

Figure 6-2 Basic settings (Second confirmation station)

Local Device Config

Device Type

Second Confirmation Station ▾

Device Name

Villa Room No.

9901

Building No.

70

☒

Unit No.

0

☐

VTO ID

8001

Management Center

888888

Management Center Call Peri...

00:00:00 ⌚

-

23:59:59 ⌚

☐

Available Call Time

Setting

DND for DMSS

Setting

Apply

Refresh

Default

Table 6-2 Basic parameter description

Parameter	Description
Device Type	Select Second Confirmation Station .
Device Name	When other devices are monitoring this VTO, the device name will appear on the monitoring image.
Villa Room No.	VTH room number. Used to call VTHs.
Building No.	Configuring the building and unit number where the device is.
Unit No.	<div>  <p>If you clear the Building No. and Unit No. checkbox, it means that there is just only 1 building and unit.</p> </div>

Parameter	Description
VTO ID	Used to differentiate each VTO, and we recommend you set it according to unit or building number, and then you can add VTOs to the SIP server by using their numbers.  The number cannot be changed when the VTO serves as the SIP server.
Management Center	It is 888888 by default.
Management Center Call Period	Configure the time if you only want to receive calls from VTH during a specific period, and then enable the function.
Available Call Time	The time period in which the VTO's calling to other devices is limited. Click Setting to set the time plan for calling.
DND for DMSS	The time period in which the calling to DMSS is not limited. Click Setting to set the time plan for calling.

Step 3 Click **Apply**.

6.2 Access Control



Different model series have varied access control functions. Here uses the example for configuring the model E series.

6.2.1 Configuration

Procedure

Step 1 Select **Local Device Config** > **Access Control** > **Config**.

Step 2 Configure the parameters.

Figure 6-3 Access control

Interval between Consecutive...
s (1-20)

Door Unlocked Duration
s (1-240)

Alarm Input/Door Detector
☐ Alarm Input
☒ Door Detector

Check Door Detector Signal ...
☐

Door Detector Alarm Thresh...
s (1-9999)

Door Detector Status
☐ NC
☒ NO

Door Detector Alarm Sound
☐

Unlock Code

Table 6-3 Access control parameter description

Parameter	Description
Interval between Consecutive Unlocks	The door can only be unlocked again after the interval.
Door Unlocked Duration	The time during which the lock stays unlocked.
Alarm Input/Door Detector	Select one of them.
Check Door Detector Signal Before Locking	Enable the function based on your needs.
Door Detector Alarm Threshold	The threshold time when the door detector alarm is triggered.
Door Detector Status	<ul style="list-style-type: none"> ● NC : Normally closed. ● NO : Normally open.

Parameter	Description
Door Detector Alarm Sound	<p>It is disabled by default.</p> <p>When it is enabled:</p> <ul style="list-style-type: none"> • Door Detector Status is NC: If the door opening time exceeds the set door detection alarm threshold, the VTO will beep. And when the door detector is closed, the VTO does not beep again. • Door Detector Status is NO: If the door closing time exceeds the set door detection alarm threshold, the VTO will beep. And when the door detector is open, the VTO does not beep again.
Unlock Code	You can connect a third-party phone, such as a SIP phone, to the VTO, and use the code to open the door remotely.

Step 3 Click **Apply**.

6.2.2 RS-485

Procedure

Step 1 Select **Local Device Config** > **Access Control** > **Extension Function** > **RS-485**.

Step 2 Configure the parameters of the lock connected through the RS-485 port.

Figure 6-4 RS-485

RS-485

RS-485

Port Type

Lock

Interval between C...

5

s (1-20)

Unlock Duration

2

s (1-240)

Unlock Code

456

☒ Lock Linkage

Apply

Refresh

Default

Table 6-4 RS-485 description

Parameter	Description
Port Type	<p>Select Lock or Card Reader as the port type. It is Lock by default.</p>  <p>When card reader is selected, fingerprint card reader and QR card reader are not supported.</p>
Interval between Consecutive Unlocks	The door can only be unlocked again after the interval.
Unlock Duration	The time during which the lock stays unlocked.
Unlock Code	You can connect a third-party phone, such as a SIP phone, to the VTO, and use the command to open the door remotely. The default command is 456.
Lock Linkage	Enable the Lock Linkage , and then select the linkage lock from the drop-down list.

Step 3 Click **Apply**.



- When the 485 module of VTO linked with security module (DEE1010B) connects to card reader, the security module has a limit on the length of the entered password (10 digits supported). Therefore, room number (6 digits) + personal password (6 digits) can not unlock the door.
- When the 485 module of VTO linked with security module (DEE1010B) connects to QR card reader or fingerprint card reader, the door cannot be unlocked because the RS-485 of VTO does not support QR code and fingerprint transmission.
- When the 485 module of VTO linked with security module (DEE1010B) connects to card reader, cards cannot be issued through the 485 module and security module DEE1010B, because the 485 module does not support bidirectional command interaction.

6.3 Card Settings

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Local Device Config** > **Card Settings**.

Figure 6-5 Card settings




Table 6-5 Description of card parameters

Parameter	Description
IC Card	When enabled, IC card can be used to open the door.
IC Card Encryption & Verification	When enabled, the IC card is encrypted. Swipe the right card with successful encryption detection to open the door.



External card readers do not support encrypted IC cards.

Step 3 Click **Apply**.

6.4 Wiegand Settings

Supports access Wiegand devices. Configure the mode and the transmission mode according to your actual devices.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Local Device Config** > **Wiegand Settings**.
- Step 3 Configure the Wiegand parameters.

Figure 6-6 Wiegand input




Figure 6-7 Wiegand output

Wiegand Settings
☐ Wiegand Input
☒ Wiegand Output

Wiegand Output Type

Wiegand 34

Pulse Width (μs)

200

(20-200)

Pulse Interval (μs)

1000

(200-5000)

The pulse width is a multiple of 10 and has a multiple relationship with the pulse interval.

Output Data Type
☐ Card Number
☒ No.

Output Format

Hexadecimal

Apply

Refresh

Default

Table 6-6 Description of Wiegand parameters

Parameter		Description
Wiegand Settings		<ul style="list-style-type: none"> Select Wiegand Input when other recognition devices are connected. Select Wiegand Output when the VTO works as the recognition device. You can connect the access controller or other devices to the VTO.
Wiegand Input	Card No. Inversion	When the third party devices are connected, if the card number order recognized by the device is different from the actual card number, enable this function to correct it.
	Input Door Channel	Select the channel from Local Lock and External Lock .
Wiegand Output	Wiegand Output Type	Select a Wiegand format to read card numbers or ID numbers. <ul style="list-style-type: none"> Wiegand26 : Reads three bytes or six digits. Wiegand34 : Reads four bytes or eight digits. Wiegand66 : Reads eight bytes or sixteen digits.
	Pulse Width	Enter the pulse width and pulse interval of Wiegand output.

Parameter		Description
	Pulse Interval	
	Output Data Type	Select the type of output data. <ul style="list-style-type: none"> ● Card Number : Outputs data based on user's first card number. ● No. : Outputs data based on user ID.
	Output Format	When the output data type is configured as number, select from Decimal and Hexadecimal .

Step 4 Click **Apply**.

6.5 Layout (Multiple Buttons)

This function is only available for select models with multiple buttons (1 button, 2 buttons and 4 buttons). Here is an example of configuration for the VTO that has one button installed on its device.

Procedure

- Step 1 Log in to the webpage of the VTO.
- Step 2 Select **Local Device Config** > **Layout**.
- Step 3 Click the nameplates next to where you have installed the button(s), and then select the room number(s) from the **Room No.** you want to bind. For example, 9901, 9902, 9903 and 9904.



- You need to first configure the room number. Otherwise, you have no room number to select from in the module list. VTH room numbers is configured in **Device Setting**.
- You need to configure the room number based on your installation position of buttons. For example, if you have only installed one button next to the first nameplate, then you need to click the module of first nameplate to configure the room number on the webpage. If you have installed one button next to the fourth nameplate, then you need to click the module of fourth nameplate to configure the room number on the webpage. Keep the above configuration rule when you install 2 buttons or 4 buttons on the VTO and configure the corresponding room numbers on the webpage.

Figure 6-8 Fourth button installation




Figure 6-9 Configure the fourth nameplate for room number (1)





Figure 6-10 Configure the fourth nameplate for postal worker unlock (2)



Step 4 Click **Apply** to save the selected room number.

Step 5 If you want to bind room numbers when you install 2 buttons or 4 buttons for the VTO, repeat Step 3 to Step 4 until you have configured all of the room numbers.

7 Device Setting

This chapter introduces how to add, modify, and delete VTO, VTH, VTS, and IPC, and how to send messages from the SIP server to VTOs and VTHs when the VTO works as the SIP server. If you are using other servers as the SIP server, see the corresponding manual for details.

7.1 VTO Management

You can add VTOs to the SIP server, and all the VTOs connected to the same SIP server can call each other.

Procedure

- Step 1 Log in to the webpage of the VTO that works as the SIP server.
- Step 2 Select **Device Setting**.
- Step 3 Click **Add**.
- Step 4 Configure the parameters.

Figure 7-1 Add VTO

The screenshot shows a web-based configuration window titled "Add" with a close button (X) in the top right corner. The window contains the following fields and controls:

- Device Type:** A dropdown menu currently showing "VTO".
- * No.:** A text input field containing the value "8001".
- * Registration Password:** A password input field represented by dots.
- Building No.:** An empty text input field.
- Unit No.:** An empty text input field.
- * IP Address:** A text input field containing "127 . . .".
- * Username:** A text input field containing the value "admin".
- * Password:** A password input field represented by dots.
- Buttons:** "OK" and "Cancel" buttons are located at the bottom right of the dialog.

Table 7-1 Add VTO configuration

Parameter	Description
Device Type	Select VTO .
No.	The VTO number you configured.
Registration Password	Leave it as default.

Parameter	Description
Building No.	Available only when the platform servers or VTS work as the SIP server.
Unit No.	
IP Address	IP address of the VTO.
Username	User name and password used to log in to the webpage of the VTO.
Password	

Step 5 Click **OK**.

Related Operations

- Click  to edit the VTO.
- Click  to delete added VTOs, but the one that you have logged in to cannot be modified or deleted.

7.2 VTH Management

You can add room numbers to the SIP server, and then configure the room number on the VTHs to connect them to the network.

Procedure

Step 1 Log in to the webpage of the SIP server.

Step 2 Select **Device Setting**.

Step 3 Click **Add**.

Step 4 Configure the parameters.

- Select the device type as **VTH**.

Figure 7-2 Add VTH one by one

The screenshot shows a dialog box titled "Add" with a close button (X) in the top right corner. The dialog contains the following fields and controls:

- Device Type:** A dropdown menu with "VTH" selected.
- Add Mode:** A dropdown menu with "Add One by One" selected.
- First Name:** A text input field with the placeholder "Please enter".
- Last Name:** A text input field with the placeholder "Please enter".
- Alias:** A text input field with the placeholder "Please enter".
- * Room No.:** A text input field with the placeholder "Please enter".
- Registration Mode:** A dropdown menu with "Public" selected.
- * Registration Password:** A password input field with masked characters "*****" and a toggle icon for visibility.
- Floor:** A text input field.
- Buttons:** "OK" and "Cancel" buttons at the bottom right.

Table 7-2 Parameters description

Parameter	Description
First Name	Enter the information you need to differentiate each room.
Last Name	
Alias	
Room No.	Enter a room number, and then configure the number on a VTH to connect it to the network.
Registration Mode	Select Public .
Registration Password	Leave it as default.
Floor	<p>Select the floor which can be given the permission.</p>  <p>This parameter is available only when Lift Control Mode is selected as With Lift Controller.</p>

- Select the add mode as **Add in Batches**.



- ◇ **Add in Batches** is not available when the device mode is set to villa.

- ◇ If the device has been added to the DoLynk Pro, no matter what device type is, the **Add in Batches** is available.

Figure 7-3 Add VTH in batches

Table 7-3 Parameters description

Parameter	Description
Floors in Unit	Configure the numbers of floors and rooms.
Rooms on Each Floor	
First Room No. on 1st Floor	Configure the first room number on the first and second floor, the room number will be automatically generated.
First Room No. on 2nd Floor	

Step 5 Click **OK**.



- Click  to edit the VTH, or  to delete added VTHs, but the one that you have logged in to cannot be modified or deleted.
- Click  or  to call or hang up VTH.



- ◇ It is only available when SIP function is online.
- ◇ If the group call is enabled, the group call will be performed when call #0 or -0 VTH.
- ◇ The calling function is only available for VTH.

7.3 VTS Management

You can add a VTS to the SIP server, and then it can be used as the management center. It can also manage, call, or receive calls from all the VTOs and VTHs in the network. See the corresponding user's manual for details.

Procedure

- Step 1 Log in to the webpage of the VTO that works as the SIP server.
- Step 2 Select **Device Setting**.
- Step 3 Click **Add**.
- Step 4 Configure the parameters.

Figure 7-4 Add VTS

Add

X

Device Type

VTS

* VTS No.

Please enter

* IP Address

* Registration Password

.....

OK

Cancel

Table 7-4 Add VTS configuration

Parameter	Description
Device Type	Select VTS .
VTS No.	The number of the VTS.
Registration Password	Leave it as default.
IP Address	VTS IP address.

- Step 5 Click **OK**.

8 Person Management

Background Information



The card and fingerprint information that registered on the VTO will be uploaded to the person management in real time.

Procedure

Step 1 Log in to the webpage.

Step 2 Select **Person Management**.

Figure 8-1 Person management

Add	Import Person	Export Person	Delete	Clear	Refresh	Person ID/Room No./Username <input type="text"/>	
☐	No.	Person ID	Room No.	Username	Verification Mode	Operation	
☐	1	1	1	rh81f0c3n3d9xwi2a	3		
☐	2	2	2	e3tb2gy8q7qjm1d6	1		
☐	3	10000001	300	b4zgjy57eomk6rh81f0c3n3d9xwi2a	2		
☐	4	10000002	301	z5shofvwxnll0n4e3tb2gy8q7qjm1d6	2		
☐	5	10000003	302	ka4jugbqro215lpxzfycfwt7dvm38s	2		
☐	6	10000004	303	l5k18r6dbwgtm7jyfe92apcuvon34sz	2		
☐	7	10000005	304	ukr2fth5z4bsm8eaq6j0w3x1v7ycon	2		
☐	8	10000006	305	l6odx0vkczwb1hiysjap57zfrn94gq	2		
☐	9	10000007	306	teu7r6amdphlowsx12fb5yc8v0q4njz	2		
☐	10	10000008	307	8n5ytka9fzao0ecwrd1hvjmi62ulgb3	2		
5000 records							
<div>< 1 2 3 4 5 ... 500 > 10 / page Go to Page</div>							

Step 3 Click **Add**.

Step 4 Configure the parameters, and then click **OK**.

Figure 8-2 Add the person

Add
×

* Person ID

* Room No.

Username

* Validity Period

Forever ▾

* Lock Permission

☒ Local Lock
☒ External Lock

Multi-Door Unlock ⓘ

☐

Verification Mode

> Password
Not Added

> Card
Not Added

OK

Cancel

Table 8-1 Person parameters description

Parameter	Description
Person ID	Customize the number.
Room No.	Enter the corresponding room number of the VTH.
Username	Enter the user name.
Validity Period	Configure the validity period during which people have access permissions.
Lock Permission	Set the lock permission. You can enable the permission for local lock and external lock at the same time.
Multi-Door Unlock	<p>When verification is successful, the local lock and external lock will open at the same time.</p> <p></p> <p>Personal password does not support this function.</p>
Password	<ol style="list-style-type: none"> Select Password > Add. Enter the password, and then confirm it again. <p></p> <p>The password must consist of 4-6 digits.</p> <ol style="list-style-type: none"> Click OK.

Parameter	Description
Card	<ol style="list-style-type: none"> 1. Select Card > Add. 2. Enter the card number. Or you can click Issue Card, and then swipe the card on VTO. 3. Click OK. <p>You can manage the cards through the following icons.</p> <ul style="list-style-type: none"> •  /  : Configure the card as the main card or general card. •  : If you lost your card, click to report the loss. The icon becomes . •  : The card cannot be used to open the door. Click it to make the card valid. •  : Edit the card name. •  : Delete the card.
Floor	<p>Select the floor which can be given the permission.</p>  <p>This parameter is available only when Lift Control Mode is selected as Without Lift Controller.</p>

9 Network Settings

This chapter introduces how to configure the network parameters.

9.1 TCP/IP

You need to configure the TCP/IP information to connect the VTO to the network.

Procedure

- Step 1 Log in to the webpage of the VTO.
- Step 2 Select **Network Settings** > **TCP/IP**.
- Step 3 Configure the TCP/IP parameters.

Figure 9-1 TCP/IP

The screenshot displays the TCP/IP configuration page. At the top, there is a 'DHCP' toggle switch. Below this, several network parameters are listed with corresponding input fields: 'MAC Address', 'IP Address', 'Subnet Mask', and 'Default Gateway'. Each of these fields is currently filled with placeholder text. Below these are the 'Preferred DNS' and 'Alternate DNS' fields, which contain the IP addresses '8.8.8.8' and '8.8.4.4' respectively. At the bottom of the configuration area, the 'Transmission Mode' is set to 'Multicast' via a selected radio button, with 'Unicast' as an alternative. Three action buttons are located at the bottom: 'Apply' (highlighted in blue), 'Refresh', and 'Default'.

Table 9-1 Parameter description

Parameter	Description
DHCP	Automatically assigns IP addresses and other network configuration parameters.
IP Address	Your planned IP address for the VTO.

Parameter	Description
Preferred DNS	It is 8.8.8.8 by default.
Alternate DNS	It is 8.8.4.4 by default.
Transmission Mode	<ul style="list-style-type: none"> • Multicast: Ideal for video talk. • Unicast: Ideal for group call.  <p>Unicast is not recommended when the platform is being used as an SIP server.</p>

Step 4 Click **Apply**.


9.2 Port

Procedure

Step 1 Select **Network Settings** > **Port**.

Step 2 Configure the parameters.

Figure 9-2 Port



TCP Port	37777	(1025-65535)
UDP Port	37778	(1025-65535)
HTTP Port	80	
HTTPS Port	443	

Buttons: Apply, Refresh, Default

Table 9-2 Parameter description

Parameter	Description
TCP/UDP Port	Used for accessing the VTO with devices in other networks.
HTTP Port	You can now enter http://VTO IP address: HTTP Port to log in to the VTO.
HTTPS Port	You can now enter https://VTO IP address: HTTPS Port to log in to the VTO.

Step 3 Click **Apply**.

9.3 SIP Server

There must be a SIP server in the network for all connected VTOs and VTHs to call each other. You can use a VTO or other servers as the SIP server.

Procedure

Step 1 Select **Network Settings** > **SIP Server**.

Step 2 Select a server type.

- The VTO you have logged in as the SIP server: Enable **Local SIP Server**, and then configure the parameters for the VTO.



Some parameters would become grey after enabling the **Local SIP Server** function.

Figure 9-3 Current VTO as SIP server

Local SIP Server ☒

Port

SIP No.

Registration Password

SIP Domain

Cascade SIP Server ☐

Backup SIP Server ☐

- If another VTO works as the SIP server: Select the SIP type as **Device**, and then configure the parameters for the VTO working as the SIP.



If the VTO you have logged in does not work as the SIP server, do not enable **Local SIP Server**. Otherwise, the connection would fail.

Figure 9-4 Another VTO as SIP server

Local SIP Server

Server Type

Device

Server Address

Port

5060

SIP No.

8001

Registration Password

SIP Domain

VDP

SIP Server Username

admin

SIP Server Password

Apply

Refresh

Default

Table 9-3 SIP server configuration (VTO as the SIP server)

Parameter	Description
Server Address	Planned IP address of the VTO.
Port	5060 by default.
SIP No.	VDP by default. Leave it as default.
Registration Password	
SIP Domain	
SIP Server Username	Username and password used to log into the webpage of the SIP server.
SIP Server Password	

- The DSS platform works as the SIP server: Set **Private SIP Server** as **Server Type**, and then configure the parameters.

Figure 9-5 Private SIP server

Table 9-4 SIP server description (platform as the SIP server)

Parameter	Description
Server Address	IP address of the SIP server.
Port	5080 by default when the platform works as the SIP server.
SIP No.	Leave it by default.
Registration Password	
SIP Domain	
Device as Alternate Server	Enable it so that you can configure the Alternate VTS IP.
Alternate IP	<p>The alternate server will be used as the SIP server when Express or DSS stops responding. We recommend you configure the alternate IP address.</p> <p></p> <ul style="list-style-type: none"> ◇ If you enable Device as Alternate Server, the current VTO you have logged in serves as the alternate server. ◇ If you want another VTO serve as the alternate server, you need to enter the IP address of that VTO in the Alternate IP textbox. Do not enable Device as Alternate Server in this case.
Alternate Server Username/ Password	Used to log in to the alternate server.
Alternate VTS IP	IP address of the alternate VTS.

Step 3 Click **Apply**.



- For some third-party servers, if the intercom selects two unlocking methods of the **RFC 2833** and **SIP INFO** at the same time, the unlocking code will not available to unlock the intercom.
- When a third-party server is used to support a third-party intercom, the intercom exception or SIP offline may occur on some servers.

- If **Third-party Server-Asterisk** and **SIP Intercom** select two unlocking methods of the **RFC 2833** and **SIP INFO** at the same time, the unlocking code will not available to unlock the intercom.
- If IB intercom frequently disconnects from the 3CX server, the mapping relationship needs to be deleted.

9.4 Second Confirmation Station Cascading

It applied to the situation when the second confirmation station cascades to the VTH.

Prerequisites

The software version of the VTH must be V4.7 and later.

Procedure

Step 1 Select **Network Settings** > **SIP Server**.

Step 2 Configure the second confirmation station information in **Local Device Config** > **Basic Settings**.



The device type should be set as **Second Confirmation Station**.

Step 3 Set **Server Type** as **Device**, and then configure the parameters.

In this cascading situation, the VTH works as the SIP server.

Figure 9-6 SIP server configuration (VTH as the SIP server)

Local SIP Server ☐

Server Type: Device

Server Address: [blurred]

Port: 5060

SIP No.: 8001

Registration Password: [masked]

SIP Domain: VDP

SIP Server Username: admin

SIP Server Password: [masked]

Buttons: Apply, Refresh, Default

Table 9-5 SIP server configuration description (VTH as the SIP server)

Parameter	Description
Server Address	Your planned IP address of the VTH.
Port	5060 by default.
SIP No.	Leave it as default.
Registration Password	
SIP Domain	
SIP Server Username	Username and password used to log into the VTH that serves as the SIP server.
SIP Server Password	

Step 4 Click **Apply**.

9.5 Cloud Service

Enable the **Cloud Service** function, and then you can scan the QR code with your phone to add the VTO to the app on your phone.

Figure 9-7 Cloud service

Enable ☒

After the function is enabled and the device connects to the network, we will collect device information such as the IP address, MAC address, device name and serial number. The collected information will only be used to remotely access the device. If you do not want to enable this function, please clear the selection from the check box.

P2P Status ● Offline

PaaS Status ● Offline

SN A 6



Apply

Refresh

Default

9.6 Wi-Fi


If the VTO supports Wi-Fi function, then configure the parameters here.

Procedure

- Step 1 Log in to the webpage of the VTO.
- Step 2 Select **Network Settings** > **Wi-Fi**.
- Step 3 Set the **Wi-Fi** status as **On**.
All the networks available are displayed.

60

Figure 9-8 Wi-Fi



Name	Signal Strength	Status	Connect
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+
[blurred]	[signal icon]		+

Step 4 Click + of the Wi-Fi you chose, enter the password of it, and then connect to the network.

9.7 Basic Services


Configure functions that involve device security.

Procedure

Step 1 Select **Network Settings** > **Basic Services**.

Step 2 Enable the security functions based on your needs.

Figure 9-9 Basic services



SSH ☒

⚠ There might be safety risk if this service is enabled.

CGI ☒

Mobile Push Notifications ☒

Password Reset ☒

ONVIF ☒

Outbound Protection of S... ☐

⚠ There might be data leakage risk if this service is disabled.

Multicast/Broadcast Search ☒

Authentication Mode Security Mode (Recommended) ▾

Emergency Maintenance ☐

⚠ For easy access to our after-sales service, enable this function. If the device has any trouble performing functions, such as updating, the system will automatically enable this function.

Password Expires in Never ▾

Private Protocol ☒

⚠ *Before enabling private protocol TLS, make sure that the corresponding device or software supports this function.

TLSv1.1 ☐

LLDP ☐

Apply Refresh Default

Table 9-6 Security parameter description

Parameter	Description
SSH	<p>A secure alternative to unsecured remote protocols.</p>  <p>We recommend you turn it off because there might be safety risk if this service is enabled.</p>
CGI	<p>The use of CGI command.</p>  <p>We recommend you turn it off. Otherwise, the VTO might be exposed to security risks and data leakage.</p>
Mobile Push Notification	<p>Send information to the app on the phone.</p>  <p>We recommend you turn it off if you do not need this function. Otherwise, the VTO might be exposed to security risks and data leakage.</p>
Password Reset	If turned off, you will not be able to reset password.
ONVIF	Allows the communications between devices of the different brand or series.
Outbound Protection of Service Information	<p>Protect your passwords.</p>  <p>We recommend you turn it on. Otherwise, the VTO might be exposed to security risks and data leakage.</p>
Multicast/Broadcast Search	<p>Enable it so that the VTO will be found by other devices.</p>  <p>We recommend you turn it off. Otherwise, the VTO might be exposed to security risks and data leakage.</p>
Authentication Mode	<ul style="list-style-type: none"> ● Security Mode (recommended): Support logging in with Digest authentication. ● Compatibility Mode : Use the old login method.  <p>We recommend you use the security mode. Compatible mode might expose the VTO to security risks and data leakage.</p>
Emergency Maintenance	For easy access to our after-sales service, enable this function. If the device has any trouble performing functions, such as updating, the system will automatically enable this function.
Password Expires in	<ul style="list-style-type: none"> ● Select an expiration period from 30 days, 60 days, 90 days, 180 days, Custom and Never. ● If you select Custom, you need to configure an expiration day between 0 and 180.

Parameter	Description
Private Protocol	Before enabling private protocol TLS, make sure that the corresponding device or software supports this function.
TLSv1.1	 We recommend you turn it off because there might be safety risk if this service is enabled.
LLDP	Improves the efficiency of information exchange among network devices.

Step 3 Click **Apply**.

9.8 Auto Registration

VTO automatically registers on the server, and reports its IP address to the designated server.

Procedure

Step 1 Log in to the webpage of VTO.

Step 2 Select **Network Settings** > **Auto Registration**.

Step 3 Enable the function. Enter the server address, port number and registration ID.

Figure 9-10 Auto registration




Table 9-7 Parameters description

Parameter	Description
Server Address	IP address or domain name of the server that is needed in registration.
Port	Port number that the server automatically registers.
Registration ID	The server distributes an ID for the device. Keep consistent with the ID registered on the server.

Step 4 Click **Apply**.

10 System

10.1 Alarm

Procedure

Step 1 Select **System** > **Alarm**.

Figure 10-1 Alarm

Step 2 Configure the parameters, which will take effect upon change.

Table 10-1 Alarm parameter description

Parameter	Description
Calling Alarm	When the call is initiated, the alarm output will be linked. If the alarm out interface is connected with a buzzer, it will beep.
Tamper Sound	Configure whether the device whistles locally or not. It is enabled by default.
Report Event	Configure whether the device reports the tamper alarm to the App, indoor unit, and back-end of the platform or not. It is enabled by default.
Restore Device for Multiple Tamper Alarms	Within 10 minutes after the device is powered on, if you continuously press the tamper button for 5 times in 8 seconds, the device beeps and deletes the account information.

Step 3 Click **Apply**.

10.2 Video

Configure the video format and quality, and audio of the VTO.

Procedure

Step 1 Select **System** > **Video**.

Figure 10-2 Video

Step 2 Configure the parameters, which will take effect upon change.

Table 10-2 Video parameter description

Parameter			Description
Bit Rate	Main Stream	Resolution	<ul style="list-style-type: none">● 720P : 1280 × 720.● WVGA : 800 × 480.● D1 : 704 × 576.● CIF : 352 × 288.
		Frame Rate (FPS)	<ul style="list-style-type: none">● If select the Video Standard as PAL: The range is 1 to 25.● If select the Video Standard as NTSC: The range is 1 to 30. <p>The larger the value, the smoother the video, but it requires more bandwidth.</p>
		Bit Rate	The larger the value, the better the video quality, but it requires more bandwidth.
		Compression	Compared with H.264, H.265 requires smaller bandwidth.

Parameter			Description
	Sub Stream	Resolution	<ul style="list-style-type: none"> ● 1080P : 1920 × 1080. ● 720P : 1280 × 720. ● WVGA : 800 × 480. ● QVGA : 320 × 240. ● D1 : 704 × 576. ● CIF : 352 × 288.
		Frame Rate (FPS)	The range is 1 to 25. The larger the value, the smoother the video, but it requires more bandwidth.
		Bit Rate	Include 224 Kbps, 256 Kbps, 320 Kbps, 384 Kbps, 448 Kbps, 512 Kbps, 640 Kbps, 768 Kbps. The larger the value, the better the video quality, but it requires more bandwidth.
		Compression	H.264. H.265.
Status	Scene Mode		Select from Auto , Disable , Sunny and Night . Auto is selected by default.
	Compensation Mode		<ul style="list-style-type: none"> ● BLC : Back light compensation. Improve the clarity of the target in the image. ● WDR : Wide dynamic range. Enhance the brightness of dark areas, and reduce the brightness of bright areas to improve the image. ● HLC : High light compensation. Reduce the brightness of the strong spots to improve the overall image. ● Disable: Do not use any compensation mode.
	Day/Night		Select from Color , Auto and B/W .
	Video Standard		Select PAL or NTSC according to your area.
	Sign Light		Configure the sign light.
Exposure	Anti-flicker		<ul style="list-style-type: none"> ● 50Hz : The system adjusts the exposure according to ambient light automatically to ensure that stripes do not appear. ● 60Hz : The system adjusts the exposure according to ambient light automatically to ensure that stripes do not appear. ● Outdoor : If you select Outdoor, the exposure mode can be set to Gain Priority, Shutter Priority and Iris Priority. Different devices support different exposure modes.

Parameter		Description
	Exposure Mode	<ul style="list-style-type: none"> • Auto : Exposure is automatically adjusted according to scene brightness if the overall brightness of images is in the normal exposure range. • Manual : You can adjust the Gain and Shutter value manually. • Shutter Priority : The camera automatically adjusts the aperture size based on the selected shutter speed to ensure proper exposure.
	Exposure Compensation	You can set the exposure compensation value. The value ranges from 0 to 100. The higher the value is, the brighter the image will be.
	3D NR	Reduce the noise of multiple-frame (at least two frames) images by using inter-frame information between two adjacent frames in a video. The higher the level is, the lower the noise will be, and the larger the trailing smear will be.
	NR Level	Noise reduction grade. The value ranges from 0 to 100. The larger the value is, the less the noise will be.
Image	Brightness	The larger the value, the brighter the image.
	Contrast	Larger value for more contrast between bright and dark areas.
	Hue	Make the color brighter or darker. The default value is made by the light sensor, and we recommend keeping it default.
	Saturation	The larger the value, the thicker the color.
	Mirror	Display the image with left and right side reversed.
	Flip	Display the image upside down.
	Display Time	Display the current time and date on the video image.

Related Operations

Click **Default** to restore to default configurations.

10.3 Audio

Procedure

Step 1 Select **System** > **Audio**.

Step 2 Configure the parameters, which will take effect upon change.

Figure 10-3 Audio

Audio Control

Voice Prompt while Ringing ☒
Ringtone ☒
Unlock ☒
Alarm ☒
Voice Messages ☒
Audio Collection ☒

Volume Control

Intercom Volume + 0
Microphone Volume + 0
Device Volume + 0

Audio File(Please upload a WAV or MP3 file. The file size must not exceed 100K.)

Audio Type	Audio File	Modify
Calling	-	
Busy	-	
Successfully Unlocked	-	
Nobody Answered	-	
Call Ended	-	
Nonexistent Number	-	

Table 10-3 Audio parameter description

Parameter		Description
Audio Control	Voice Prompt while Ringing	Turn on or off each type of sound.
	Ringtone	
	Alarm	
	Voice Messages	
	Unlock	
	Audio Collection	
Volume Control	Microphone Volume	Adjust the microphone volume of the VTO. The higher the value is, the higher the volume will be.
	Intercom Volume	Adjust the speaker volume. The higher the value is, the higher the volume will be.
	Device Volume	Adjust the device volume. The higher the value is, the higher the volume will be.

Step 3 Click **Apply**.

Step 4 (Optional) Upload audio file by clicking next to the corresponding audio type (including calling, busy, successfully unlocked, nobody answered, call ended and nonexistent number).



Please upload a WAV or MP3 file. The file size must not exceed 100K.

10.4 Time

Configure the time zone and day light saving parameters.

Procedure

Step 1 Select **System** > **Time**.

Step 2 Configure the time and time zone and DST.

Figure 10-4 Time

Time and Time Zone



Date :
2023-07-10 Monday
Time :
13:46:16

Time ☒ Manually Set ☐ NTP

System Time

Time Format

Time Zone

DST

Enable ☐

Type ☐ Date ☒ Week

Start Time

End Time

Table 10-4 Parameter description

Module	Parameter	Description
Time and Time Zone	Time	<ul style="list-style-type: none">Manually SetNTP

Module	Parameter	Description
	System Time	<p>The time of the VTO system.</p>  <p>Changing system time might cause problems on video searching and information publication. Turn off video recording and auto snapshot before changing it.</p>  <p>Only applicable in the Manually Set mode.</p>
	Sync PC	<p>Synchronize the VTO system time with your PC.</p>  <p>Only applicable in the Manually Set mode.</p>
	Server	<p>The address of the NTP server.</p>  <p>Only applicable in the NTP mode.</p>
	Manual Update	<p>Click the icon and the device time of the VTO will be automatically synchronized with server.</p>  <p>Only applicable in the NTP mode.</p>
	Port	<p>NTP server port number.</p>  <p>Only applicable in the NTP mode.</p>
	Interval	<p>VTO time update cycle. 30 minutes at most.</p>  <p>Only applicable in the NTP mode.</p>
	Time Format	<p>For the date format, select from one of the following:</p> <ul style="list-style-type: none"> • YYYY-MM-DD • MM-DD-YYYY • DD-MM-YYYY <p>For the time format, select from one of the following:</p> <ul style="list-style-type: none"> • 24-Hour • 12-Hour
	Time Zone	Select the time zone for the VTO system.
DST	Enable	Click to enable the DST function.
	Type	Select Date or Week as needed, and then configure the specific period.
	Start Time	Configure the start time and end time of DST.
	End Time	

Step 3 Click **Apply**.

10.5 ONVIF User

Add accounts for devices to monitor the VTO through the ONVIF protocol.



Only Profile C and Profile S are supported, while the encoding format and image parameters are not supported.

Procedure

Step 1 Select **System** > **ONVIF User**.

Step 2 Click **Add**.

Step 3 Enter the information, and then click **OK**.

ONVIF devices can monitor the VTO by using the account.

Figure 10-5 ONVIF user

The screenshot shows a web-based 'Add' dialog box for creating an ONVIF user. The dialog has a title bar with the word 'Add' and a close button (X). Inside the dialog, there are three input fields, each preceded by a red asterisk indicating a required field:

- * Username:** The input field contains the text 'Jack'.
- * Password:** The input field contains masked characters (dots). Below the field is a password strength indicator consisting of two horizontal bars: a yellow bar and a blue bar.
- * Confirm Password:** The input field contains masked characters (dots).

At the bottom right of the dialog, there are two buttons: a blue 'OK' button and a white 'Cancel' button with a grey border.

11 Maintenance Center

11.1 One-Click Diagnosis

The system automatically diagnoses the configurations and the status of the device to improve its performance.

Procedure

Step 1 Log in to the webpage.

Step 2 Select **Maintenance Center** > **One-click Diagnosis**.


Step 3 Click **Diagnose**.

The system automatically diagnoses the configurations and the status of the device and display diagnosis results after it completes.

Step 4 (Optional) Click **Details** to view details of abnormal items.

You can ignore the abnormality or optimize it. You can also click **Diagnose Again** to perform automatic diagnosis again.

Figure 11-1 One-click diagnosis



11.2 System Information

11.2.1 Version Information

Procedure

Step 1 Select **Maintenance Center** > **System Info** > **Version**.

Step 2 View the software version, SCM version and security baseline version.

Figure 11-2 System information

Device Model	VTO3312Q-P
Device SN	A 5
Hardware Version	V1.00
Software Version	2025-05-23 V4.800.0000001.0.R
Web Version	V5.011.0.250522.2490186
Security Baseline Version	V2.4

11.2.2 Legal Information

Select **Maintenance Center** > **System Info** > **Legal Info**. You can view related legal information notices in this section.

11.3 Data Capacity

You can see how many users, cards and face images that the VTO can store.

Log in to the webpage and select **Maintenance Center** > **Data Capacity**.

11.4 Log Management

Select **Maintenance Center** > **Log**. You can search for different logs, and export them to your local computer.



If storage is full, the oldest records will be overwritten. Back up the records in time.

11.4.1 Call History

Select **Maintenance Center** > **Log** > **Call History**.

Figure 11-3 Call history

Please keep unencrypted files well to avoid data leakage.					
Export					
No.	Call Type	Room No.	Start Time	Call Duration (min)	End Status
1	Incoming	9902	2000-03-18 00:40:45	00:30	Answered
2	Outgoing	9903	2000-03-17 08:51:39	00:00	Missed
3	Incoming	9904	2000-03-14 04:08:05	00:39	Answered
4	Incoming	9904	2000-03-14 04:05:57	00:19	Answered
5	Incoming	9905	2000-03-11 00:34:46	00:12	Answered
6	Incoming	9904	2000-03-10 08:11:20	00:12	Answered
7	Incoming	9904	2000-03-10 02:26:20	00:06	Answered
8	Incoming	9904	2000-03-10 02:25:54	00:21	Answered
9	Incoming	9904	2000-03-10 02:25:09	00:44	Answered
10	Incoming	9904	2000-03-10 00:53:06	00:06	Answered
681 records					
<div> < 1 2 3 4 5 ... 69 > 10 / page Go to Page </div>					

11.4.2 Alarm Logs

Select **Maintenance Center** > **Log** > **Alarm Logs**.

Figure 11-4 Alarm

Please keep unencrypted files well to avoid data leakage.				
Export				
No.	Room No.	Event	Channel	Start Time
1	8001	Tamper	1	2023-07-11 02:00:53
2	8001	Tamper	1	2023-07-07 10:07:18
3	8001	Tamper	1	2023-07-06 22:16:19
4	8001	Tamper	1	2023-07-06 22:09:52
5	8001	Tamper	1	2023-07-04 02:00:49
6	8001	Tamper	1	2023-06-29 16:29:49
7	8001	Tamper	1	2023-06-29 16:26:59
8	8001	Tamper	1	2023-06-29 15:22:09
9	8001	Tamper	1	2023-06-29 15:22:08
10	8001	Tamper	1	2023-06-27 14:07:57
12 records				
<div> < 1 2 > 10 / page Go to Page </div>				

11.4.3 Unlock Records

Select **Maintenance Center** > **Log** > **Unlock Records**.

Figure 11-5 Unlock Records

Please keep unencrypted files well to avoid data leakage.

Export

Time Range21-10-2024 00:00:00 → 22-10-2024 00:00:00

Search

No.	Unlock Method	VTO ID	Person ID	Room No.	Username	Card	Lock	Unlock Results	Unlock Time
1	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:42
2	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:37
3	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:36
4	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:35
5	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:33
6	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:31
7	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:30
8	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:29
9	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:27
10	Card Swipe Unlock	8004				FBFA192A	Local Lock	Failed	2024-10-21 11:13:25

1000 records

<

1

2

3

4

5

...

100

>

10 / page

Go to

Page

11.4.4 Log

Select **Maintenance Center > Log > Log**.
Select time range and type, and then you can see all the log information.

Figure 11-6 Log

Please keep unencrypted files well to avoid data leakage.

Time Range2023-07-10 00:00:00 → 2023-07-11 00:00:00

TypeAll

Search

Reset

☐ Encrypt Log Backup

Export

No.	Time	Type	Log Content
<div><div></div><div>No Data</div></div>			

11.5 Maintenance Management

11.5.1 Config

You can export and import the configuration file.
Procedure

- Step 1

Select **Maintenance Center > Maintenance Management > Config**.
- Step 2

Click **Export Configuration File**, or click **Browse** to select the file from local computer, and then click **Import file**.

Figure 11-7 Config

The screenshot shows a web interface titled "Config". It contains an "Export Configuration File" button. Below it, there is a "File" label followed by a text input field, a "Browse" button, and an "Import File" button. At the bottom, a yellow warning box contains a yellow circle with an exclamation mark and the text "Imported configuration will overwrite previous configuration."

11.5.2 Maintenance

Procedure

- Step 1 Select **Maintenance Center > Maintenance Management > Maintenance**.
- Step 2 Configure the auto maintenance time.

Figure 11-8 Auto maintenance

The screenshot shows a web interface titled "Maintenance". Under the "Auto Maintenance" section, there is a "Maintenance Time" label followed by a dropdown menu showing "Tue" and a time dropdown showing "02:00". Below these are two buttons: "Apply" (in blue) and "Refresh" (in white).

- Step 3 Click **Apply**.

11.6 Update

Procedure

- Step 1 Select **Maintenance Center > Update**.
- Step 2 Select ways to check the update.
- **File Update** : Click **Browse** to add the updating file, and then click **Update**.
 - **Online Update**
 - ◇ **Auto Check for Updates** : Enable the function to check automatically whether there is a new system version.
 - ◇ **Manual Check** : Select the function to check whether there is a new system version.

Figure 11-9 Online update

Online Update

Auto Check for Updates ☐

[Manual Check](#)

System Version: 4
You are using the latest version. [Update Now](#)

11.7 Advanced Maintenance

Export

Select **Maintenance Center** > **Advanced Maintenance** > **Export** to export the serial number, firmware version, device operation logs and configuration information.

Packet Capture

1. Select **Maintenance Center** > **Advanced Maintenance** > **Packet Capture**.
2. Enter the port of the device.
3. Click ► to start the packet sniffer backup.

Figure 11-10 Packet capture

Packet Capture							
NIC	Device Address	IP 1: Port 1		IP 2: Port 2		Packet Sniffer Size	Packet Sniffer Back...
eth0	<input type="text"/>	<input type="text" value="Optional"/>	<input type="text" value="Optional"/>	<input type="text" value="Optional"/>	<input type="text" value="Optional"/>	0.00MB	►
lo	<input type="text"/>	<input type="text" value="127.0.0.1"/>	<input type="text" value="Optional"/>	<input type="text" value="Optional"/>	<input type="text" value="Optional"/>	0.00MB	►

Network Test

1. Select **Maintenance Center** > **Advanced Maintenance** > **Packet Capture**.
2. In the **Network Test** area, test the network as needed.
 - a. Enter the destination address in the box, and then click **Test**.
 - b. After you acquired enough data, click **Stop**, and then you can view the test result in the following box.
 - c. Click **Copy** to copy the test result.

Figure 11-11 Test network

Network Test

Destination Address

11112

Test

Data Packet Size

64

Byte (64-4096)

Test Result

PING 11112 64(92) bytes of data.
72 bytes from 11112: icmp_seq = 1 ttl = 123 time = 2 ms
72 bytes from 11112: icmp_seq = 2 ttl = 123 time < 1 ms
72 bytes from 11112: icmp_seq = 3 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 4 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 5 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 6 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 7 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 8 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 9 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 10 ttl = 123 time = 1 ms
72 bytes from 11112: icmp_seq = 11 ttl = 123 time = 2 ms

Copy


Round Time Used: Min = 0 ms, Max = 2 ms, Average = 1.091 ms

12 Security Management

12.1 Security Status

On the home page, click , and then select **Security Status**.

Figure 12-1 Security status




12.2 System Service

Procedure

- Step 1** On the home page, click , and then select **System Service**.
- Step 2** Select a device certificate, and then enable the HTTPS function.

Figure 12-2 System service



- Step 3** Click **Apply**.

12.3 Attack Defense


12.3.1 Firewall

You can enable different firewall types to control network access to the VTO.

Procedure

- Step 1** On the home page, click , and then select **Attack Defense** > **Firewall**.
- Step 2** Click ☐ next to **Enable**.
- Step 3** Select the **Mode** as either **Allowlist** or **Blocklist**.
- Allowlist: Devices that have been granted an access.
 - Blocklist: Devices that have been forbidden an access.
- Step 4** Click **Add** to add the IP address for allowlist or blocklist.

Figure 12-3 Add



The 'Add' dialog box is shown with the following fields and controls:

- Add Mode:** A dropdown menu currently set to 'IP'.
- IP Version:** A dropdown menu currently set to 'IPv4'.
- IP Address:** A text input field containing '10' followed by several empty boxes for the rest of the IP address.
- All Device Ports:** A toggle switch that is currently turned on (blue).
- Buttons:** 'OK' and 'Cancel' buttons at the bottom right.

- Step 5** Click **OK**.
- Step 6** Select an added IP address for allowlist or blocklist, and then click **Apply**.

Figure 12-4 Apply

The screenshot shows the Firewall configuration interface. At the top, there are tabs for 'Firewall', 'Account Lockout', and 'Anti-DoS Attack'. The 'Firewall' tab is active. Below the tabs, there is an 'Enable' toggle switch which is turned on. Under 'Mode', the 'Allowlist' radio button is selected, and the 'Blocklist' radio button is unselected. A light blue box contains the text: 'Only source hosts whose IP/MAC are in the following list are allowed to access corresponding ports of the device.' Below this box are 'Add' and 'Delete' buttons. A table with the following columns is shown: 'No.', 'Host IP/MAC', 'Port', and 'Operation'. The table contains one record with 'No.' 1, 'Host IP/MAC' 12, and 'Port' All Device Ports. Below the table, it says 'Total 1 records'. At the bottom, there are 'Apply', 'Refresh', and 'Default' buttons.

No.	Host IP/MAC	Port	Operation
1	12	All Device Ports	

12.3.2 Account Lockout

Procedure

- Step 1** On the home page, click , and then select **Attack Defense** > **Account Lockout**.
- Step 2** Configure the login attempts and lock time for device account and ONVIF user.

Figure 12-5 Account lockout

The screenshot shows the Account Lockout configuration interface. At the top, there are tabs for 'Firewall', 'Account Lockout', and 'Anti-DoS Attack'. The 'Account Lockout' tab is active. Below the tabs, there are two sections: 'Device Account' and 'ONVIF User'. Each section has 'Login Attempt' and 'Lock Time' fields. For 'Device Account', 'Login Attempt' is set to 5time(s) and 'Lock Time' is set to 5 min. For 'ONVIF User', 'Login Attempt' is set to 30time(s) and 'Lock Time' is set to 5 min. At the bottom, there are 'Apply', 'Refresh', and 'Default' buttons.


- Step 3** Click **Apply**.

12.3.3 Anti-DoS Attack

Procedure

- Step 1** On the home page, click , and then select **Attack Defense > Anti-DoS Attack**.
- Step 2** Enable or disable the **SYN Flood Attack Defense** or **ICMP Flood Attack Defense** function.

Figure 12-6 Anti-DoS attack



SYN Flood Attack D... ☐

An attacker might send out repeated SYN messages to the device, leaving many half-open TCP connections on the device, which will make the device crash. When hit by an SYN flood attack, the device will defend itself by discarding the first message.

ICMP Flood Attack ... ☐

An attacker might send out an abnormally large number of ICMP packets to the device, which will use up all computing resources and thus make the device crash. When hit by an ICMP flood attack, the device will defend itself by using the ICMP message filtering tactic.

[Apply](#) [Refresh](#) [Default](#)


- Step 3** Click **Apply**.

12.4 CA Certificate

Procedure

- Step 1** On the home page, click , and then select **CA Certificate**.
- Device Certificate

Figure 12-7 Device certificate



[Device Certificate](#) [Trusted CA Certificates](#)

A device certificate is a proof of device legal status. For example, when the browser is visiting device via HTTPS, the device certificate shall be verified.

[Install Device Certificate](#) [Enter Edit Mode](#)

No.	Custom Na...	Certificate Serial N...	Validity Period	User	Issued by	Used by	Certific...	Default	Down...	Delete
1		6330...	2053-06-19 20...	7L08CE4YA...	192.168.1.1	HTTPS, RTS...	Normal	☒		

- Trusted CA Certificates

Figure 12-8 Trusted CA certificates

Device Certificate [Trusted CA Certificates](#)

A trusted CA certificate is used to verify the legal status of a host. For example, a switch CA certificate shall be installed for 802.1x authentication.

[Install Trusted Certificate](#) [Enter Edit Mode](#)

No.	Custom Na...	Certificate Serial Nu...	Validity Period	User	Issued by	Used by	Certificate ...	Downlo...	Delete
1		3231...	2027-10-16 23:...	192.168.1.1	192.168.1.1		Normal		

12.5 Video Encryption

Procedure

Step 1 On the home page, click , and then select **Video Encryption**.

Step 2 Configure **Private Protocol** and **RTSP over TLS** parameters.

Figure 12-9 Video encryption

[Encrypted Transmission](#)

Private Protocol

Enable ☐

Stream transmission is encrypted by using private protocol.

*Please make sure that the corresponding device or software supports video decryption.

Encryption Type: AES256-OFB

Update Period: 12 hr (0-720)

RTSP over TLS

Enable ☒

RTSP stream is encrypted by using TLS tunnel before transmission.

*Please make sure that the corresponding device or software supports video decryption.

*Select a device certificate [Certificate Management](#)

No.	Custom Name	Certificate Serial Number	Validity Period	User	Issued by	Used by
1		63303339356133326136313...	2053-06-19 20:06:37	7L08CE4YA0804A5	192.168.1.1	HTTPS, RTSP over TLS

[Apply](#) [Refresh](#) [Default](#)

Step 3 Click **Apply**.

12.6 Security Warning

Procedure

Step 1 On the home page, click , and then select **Security Warning**.

Step 2 Enable event monitoring function, and then click **Apply**.

Figure 12-10 Security warning

Enable ☐

Event Monitoring

 Invalid executable programs attempting to run

 Session ID bruteforcing

 Web directory bruteforcing

 Number of session connections exceeds limit

Security warning can detect device security status in real time, and keep you informed of the security exception events immediately, so that you can deal with them timely and avoid security risks.

Apply

Refresh

Default

12.7 Security Authentication

Procedure

- Step 1

On the home page, click , and then select **Security Authentication**.
- Step 2

Configure the digest algorithm for authentication, and then click **Apply**.

Figure 12-11 Security authentication

Digest Algorithm for Authentication

Digest Algorithm for User Authentication

☒ MD5

☐ SHA256

Digest Algorithm for ONVIF User Authentication

☒ MD5

☐ SHA256

Apply

Refresh

Default

13 Button Model Configuration

The button model can be connected to the VTH to work as an alarm input button. Press the button on the front panel of the model, and then the VTH receives an alarm signal.

13.1 Cable Connection

Connect the KEY port of the button model to any one of the alarm input ports of the indoor monitor (VTH) with a cable thread.

Figure 13-1 Button model





Table 13-1 Component

No.	Name	Function
1	Press button	The button model can be connected to the VTH. Press the button on the model and the VTH receives an alarm signal.

Figure 13-2 Cable connection




13.2 VTH Configuration

After completing cable connection, you need to set the **wired zone type** as **Doorbell** on the VTH to receive alarm signals once you press the button model.

Procedure

- Step 1 Power on the VTH.
- Step 2 Select **Setting** > **Alarm** > **Wired Zone** on the VTH.

Figure 13-3 Wired zone setting



- Step 3 Set the **Type** as **Doorbell**, and configure the rest of the parameters.

Table 13-2 Parameter description

Parameter	Description	
Area	The number cannot be modified.	
NO/NC	Select NO (normally open) or NC (normally closed) according to detector type. It must be the same as detector type.	
Type	Select corresponding type according to detector type.	
Status	<ul style="list-style-type: none"> ● Instant Alarm : After armed, if an alarm is triggered, the device produces siren at once and enters alarm status. ● Delay Alarm : After armed, if an alarm is triggered, the device enters alarm status after a specified time, during which you can disarm and cancel the alarm. ● Bypass : Alarm will not be triggered in the area. After disarmed, this area will restore to normal working status. ● Remove : The area is invalid during arm/disarm. ● 24 Hour : Alarm will be triggered all the time in the area regardless of arm or disarm.  <p>A zone in Remove status cannot be bypassed.</p>	
Enter Delay	After entering delay, when armed area triggers an alarm, entering armed area from non-armed area within the delay time period will not lead to linkage alarm. Linkage alarm will be produced if delay time comes to an end and it is not disarmed.	 <p>Delay is only valid to the areas of Delay Alarm.</p>
Exit Delay	<p>After arm, Delay Alarm area will enter arm status at the end of Exit Delay.</p>  <p>If multiple areas set the exit delay, screen prompt will conform to maximum delay time.</p>	

Appendix 1 Security Recommendation

Account Management

1. Use complex passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters;
- Include at least two types of characters: upper and lower case letters, numbers and symbols;
- Do not contain the account name or the account name in reverse order;
- Do not use continuous characters, such as 123, abc, etc.;
- Do not use repeating characters, such as 111, aaa, etc.

2. Change passwords periodically

It is recommended to periodically change the device password to reduce the risk of being guessed or cracked.

3. Allocate accounts and permissions appropriately

Appropriately add users based on service and management requirements and assign minimum permission sets to users.

4. Enable account lockout function

The account lockout function is enabled by default. You are advised to keep it enabled to protect account security. After multiple failed password attempts, the corresponding account and source IP address will be locked.

5. Set and update password reset information in a timely manner

The device supports password reset function. To reduce the risk of this function being used by threat actors, if there is any change in the information, please modify it in time. When setting security questions, it is recommended not to use easily guessed answers.

Service Configuration

1. Enable HTTPS

It is recommended that you enable HTTPS to access web services through secure channels.

2. Encrypted transmission of audio and video

If your audio and video data contents are very important or sensitive, it is recommended to use encrypted transmission function in order to reduce the risk of your audio and video data being eavesdropped during transmission.

3. Turn off non-essential services and use safe mode

If not needed, it is recommended to turn off some services such as SSH, SNMP, SMTP, UPnP, AP hotspot etc., to reduce the attack surfaces.

If necessary, it is highly recommended to choose safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up complex passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up complex passwords.

4. Change HTTP and other default service ports

It is recommended that you change the default port of HTTP and other services to any port between 1024 and 65535 to reduce the risk of being guessed by threat actors.

Network Configuration

1. **Enable Allow list**

It is recommended that you turn on the allow list function, and only allow IP in the allow list to access the device. Therefore, please be sure to add your computer IP address and supporting device IP address to the allow list.

2. **MAC address binding**

It is recommended that you bind the IP address of the gateway to the MAC address on the device to reduce the risk of ARP spoofing.

3. **Build a secure network environment**

In order to better ensure the security of devices and reduce potential cyber risks, the following are recommended:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network;
- According to the actual network needs, partition the network: if there is no communication demand between the two subnets, it is recommended to use VLAN, gateway and other methods to partition the network to achieve network isolation;
- Establish 802.1x access authentication system to reduce the risk of illegal terminal access to the private network.

Security Auditing

1. **Check online users**

It is recommended to check online users regularly to identify illegal users.

2. **Check device log**

By viewing logs, you can learn about the IP addresses that attempt to log in to the device and key operations of the logged users.

3. **Configure network log**

Due to the limited storage capacity of devices, the stored log is limited. If you need to save the log for a long time, it is recommended to enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

Software Security

1. **Update firmware in time**

According to the industry standard operating specifications, the firmware of devices needs to be updated to the latest version in time in order to ensure that the device has the latest functions and security. If the device is connected to the public network, it is recommended to enable the online upgrade automatic detection function, so as to obtain the firmware update information released by the manufacturer in a timely manner.

2. **Update client software in time**

It is recommended to download and use the latest client software.

Physical Protection

It is recommended that you carry out physical protection for devices (especially storage devices), such as placing the device in a dedicated machine room and cabinet, and having access control

and key management in place to prevent unauthorized personnel from damaging hardware and other peripheral equipment (e.g. USB flash disk, serial port).